

Assembling the Elless Faucet Aerators






A. Start by dismantling the existing faucet

- 1. If there is a key handle on the faucet: use a 22 mm adjustable spanner. If not, use universal pliers. Do not squeeze the casing too hard, it might get disfigured and become difficult to loosen.
- 2. Make sure that there aren't any remains of the old gasket adhered to the spout.
- 3. Open the tap and let the water run for a few seconds to swill off any existing dirt.

B. Assembling the Elless Faucet Aerators

- 1. Put the Faucet Aerator in its place and tighten it manually as much as you can.
- 2. Open the tap and fasten the Faucet Aerator with a 22 mm adjustable spanner. You don't have to tighten it more than 1/4 1/2 rounds.









Kaggeholmsvägen 45, 122 60 Enskede Ordertel: 08- 600 50 02 • Fax 08 - 600 50 07 E-post: info@elless.com Försäljningskontor Halmstad: